


A waterproof cover to protect bandages, casts and dressings from getting wet when showering only.

Measurements


There are two measurements that are required to select the most suitable LimbCoat for the foot. All measurements to be taken in centimeters.

The Foot

Circumference: At the midpoint or point where the calf muscle is at its biggest, measure the circumference of the calf at this point.



Length: Measure from the point of where the calf circumfrence measurement was taken to the bottom of the leg by ones heel.



Useful Information to Assist in Measuring up Ones Foot

The circumference measurement must be located on the skin of muscle or fleshy skin area, so as to ensure a watertight seal.

A watertight seal depends on the point of the arm where the circumference measurement has been taken.

A circumference measurement located on a boney area or boney prominence (avoid ankles, elbows and knees) will compromise a watertight seal.